



UNITED

LABORATORIES

BIO BRIGADE



BIO BRIGADE DEVOUR-DX® is a blend of specific microbes selected for their ability to biodegrade high volumes of grease, proteins, long-chain fatty acids and bio-film that can build-up in dialysis treatment floor drains. It contains patented gram-positive bacterial strains and promicrobials which are capable of fast degradation of Fats, Oils and Grease (FOG). Regular use will reduce blockages and odors significantly.

United 248 BIO BRIGADE DEVOUR-DX®:

- Earth Smart® Certified
- Bio-based
- VOC-free
- pH range from 4.5 to 9.8
- Effective temperature range of 38° – 145°F
- Optimal temperature range of 60° – 90°F
- Treat floor drains, chaise drains, drain lines and drain hoses.

DIRECTIONS FOR USE:

This product is designed to be used in conjunction with United 247 BIO BRIGADE DRAIN MEMBRANE to treat drains utilized in dialysis treatment. Treat each drain affected at the end of each working day. Exposure to sanitation agents should be minimized.

After the final disinfecting and cleaning routine performed on dialysis equipment feeding into the drain, allow 15 minutes before treating the drain with **United 248** and United 247. After 15 minutes has passed, flush drain with clean water. Then pour in 4 ounces of **United 248** to keep drains running freely and begin controlling odors.

Once **United 248** has been fed into drains, pour 4 ounces of United 247 BIO BRIGADE DRAIN MEMBRANE into the drain. United 247 will float on the top, creating a membrane-like cap to control odors, while also working to eliminate any drain flies that feed in the drain.

DEVOUR-DX®

**KEEP OUT OF REACH OF CHILDREN.
See other cautions on back/side panel**

PRECAUCION AL USARIO:

Si usted no puede leer Ingles, pregunte a alguien que le traduzca esta etiqueta para usted antes de uso.

**Manufactured and Sold Exclusively By:
UNITED LABORATORIES, INC.
320 37th Avenue • St. Charles, IL 60174
1-800-323-2594 • www.unitedlabsinc.com**

Precautionary Statements: Avoid contact with skin and eyes.

FIRST AID MEASURES:

IF IN EYES: Flush with plenty of water for at least 15 minutes and call a physician or poison control center.

IF ON SKIN: Wash with soap and water. If irritation persists, call a physician or poison control center.

IF INHALED: Not applicable.

IF SWALLOWED: Rinse mouth and throat. Give two glasses of water to dilute product. DO NOT induce vomiting. Call a physician or poison control center.

An SDS for this product is available through United's website, www.unitedlabsinc.com, providing 24 hour access. Please read the SDS carefully and follow all directions when using or handling this product. Never reuse empty containers. Incompatible materials may adversely react.

Disposal: When container is empty, recycle, if available. If recycling is not available, wrap and place container in a trash collector. Do not puncture or incinerate.

HMS® III CODE: 0=MINIMAL 1=SLIGHT 2=MODERATE 3=SERIOUS 4=SEVERE PERSONAL PROTECTION INDEX: Glasses	HEALTH	1
	FLAMMABILITY	0
	PHYSICAL HAZARD	0
	PERSONAL PROTECTION	A